



simma

- (ES) MANUAL DE INSTRUCCIONES ORIGINAL
- (GB) ORIGINAL USER GUIDE
- (FR) MANUEL ORIGINAL D'UTILISATION
- (PO) MANUAL DE INSTRUÇÕES ORIGINAL
- (DE) URSPRÜNGLICHES GEBRAUCHSANWEISUNG
- (PL) ORYGINALNA INSTRUKCJA OBSŁUGI
- (ع) دليل المستعمل الأصلي
- (IT) MANUALE D'ISTRUZIONI ORIGINALI
- (RUS) Инструкция по эксплуатации (завода изготовителя)

CEL-36 P

CEL-42 P

CEL-52 P

CEL-55 P

C/ Albuñol, par.250
Pol. Ind. Juncaril,
18220 ALBOLOTE (Granada) ESPAÑA
Telf: (+34)958 490 410
Fax: (+34) 958 466 645
info@simasa.com
www.simasa.com

INDEX

.....	1
1. GENERAL INFORMATION.....	4
2. GENERAL DESCRIPTION.....	4
2.1 TRANSPORT	5
2.2 PICTOGRAMAS.....	5
3. ASSEMBLING INSTRUCCIONS	5
3.1 MOUNTING THE BLADES	5
3.2 REPLACING AND TIGHTENING THE BELTS	6
3.3 MAINTENANCE, INSPECTION AND CONTROL	6
4. STARTING UP AND USING THE MACHINE.....	6
5. SOLUTIONS TO MOST FREQUENT ANOMALIES	7
6. ELECTRICAL CONNECTION	7
7.2 SAFETY RECOMMENDATIONS	8
8. WARRANTY	9
9. SPARE PARTS.....	9
10. DECLARATIONS ON NOISE.....	9
11. DECLARATIONS ON MECHANIAL VIBRATIONS	9
12. ENVIRONMENT PROTECTION	9

1. GENERAL INFORMATION

WARNING: Please read and understand perfectly the present instruction before using the machine.

SIMA S.A. thanks you for your trust in our products and for purchasing the ELECTRICAL SHEAR model CEL.

This manual provides you with the necessary instructions to start, use, maintain and in your case, repair of the present machine. All aspects as far as the safety and health of the users is concerned have been stated. Respecting all instructions and recommendations guarantees safety and low maintenance. As such, reading this manual carefully is compulsory for any person responsible for the use, maintenance or repair of this machine.

It is recommended to have always this manual in an easily accessible place where the machine is being used.

2. GENERAL DESCRIPTION

SIMA S.A., ELECTRICAL SHEAR model CEL, have been designed and manufactured to be used in work sites to cut steel reinforced and flat bars for construction, using interchangeable blades, mounted onto the cutting jaws.

Any other use of the machine is considered inadequate and can cause danger. Therefore, it is expressively prohibited.

- The manual shear model CEL has been designed and manufactured to cut flat and reinforced steel bars used for construction and passive steel armatures for structural concrete by means of two interchangeable blades mounted onto the cutting jaw.
- The cutting operation is done manually by pushing the bar on the roller, dropping the bar into the cutting throat, lowering the protection guard and pressing the pedal.
- The CEL models are furnished with a ring to elevate the machine.
- The machine is equipped with wheels and handlebars to facilitate their movement and transport for short distances.
- The internal mechanical components that are subject to wearing have been treated thermally to guaranty their long durability and high performance.
- The main body of the machine is a mono-block made of cast iron.
- Cutting is performed by means a pedal or a handlebar.
- The blades are rectangular with four cutting faces.
- Internal mechanisms are bathed in oil.
- The frame of the machine is painted in oven with a highly resistance, anti-corrosion epoxy polyester paint.
- The electrical equipment of the machine complies with the EC safety norms.

2.1 TRANSPORT

For a safe transport of the machine, please follow the following instructions:

The Electrical Shear is fitted with holes on the working table to be lifted with cranes through chains or cables. The used means of transport must be safe, taking into account the form of use, the nature of the load.

WARNING: Keep away from the lifted load and be careful of its sudden displacement to avoid any possible danger during transportation, moorage, charging or discharging. Therefore the choice of the correct of the cable, chain and sling is fundamental.

The electrical shears are equipped with a ring **B, Fig.2** for its lifting or transport. The CEL models have also a transport handlebar **A, Fig.2** to move it for short distances.

IMPORTANT: During the transport of the machine, the latter should never be reversed nor be put on either side. The machine is only to rest on its four feet **Fig. 2**.

2.2 PICTOGRAMAS.

Pictograms included in the machine entail the following:



**READ INSTRUCTIONS
MANUAL**



**USE HELMET AND EYE AND EAR
DEFENDERS**



USE SAFETY GLOVES



USE SAFETY FOOTWEAR

3. ASSEMBLING INSTRUCCIONS

The machine is delivered mounted and prepared to operation.

3.1 MOUNTING THE BLADES

If one of the blades gets blunt due to frequent use, replace it as follows:

- 1 CHANGING THE FIXED BLADE.** Make sure the machine is unplugged from electricity. Lift the safety guard off the blades **A, Fig.3** taking it out from its housing. Remove the protection **B, Fig.3** fixed to the left side of the machine to have access to the screws of the blades, remove the screws **C, Fig.3** and rotate the blade **D, Fig.3** for a new set of cuttings or substitute it with a new blade if necessary.
- 2 CHANGING THE MOVEABLE BLADE.** To do this, it is necessary to remove the connecting rod from its housing **E, Fig.3**, and then proceed as to the following: when the machine is put on, switch it off by pressing the stop button. While the flywheel is making its last turns, press the pedal to push the connecting rod from its housing to have access to screws fixing the blades **F, Fig.3**. Immediately thereafter, unplug the machine off the network to avoid accidents. If the connecting rod is not out of its housing, turn gently the flywheel from the inferior part of the safeguard that covers the engine until the connecting rod is out of its housing, and then remove the screws off the blade for a new cutting face or replace it with a new one if necessary. At the end, proceed to the inverse to restore the operation of the machine.
- 3** The screws are to be tightened with a torque wrench as per the following:

CEL-36 P--0000---- 25,07Nm.

CEL-42 P / 52 P----- 84,24Nm.

CEL-55 P----- 135,13Nm.

3.2 REPLACING AND TIGHTENING THE BELTS

The machines leave the factory with the belts perfectly tightened. It is possible that due to the incorrect machine installation or long use of the machine, the belts get loose. To tighten back the belt or replace it, please consider the following steps **(Fig.4)**.

- 1 Make sure the machine is unplugged off the power supply.
- 2 Remove the safeguard of the motor.
- 3 Loosen the tensor of the motor by means of the nuts **A, B, C, and Fig.4**
- 4 Replace or tighten the belt.
- 5 Once finished, proceed to the inverse.
- 6 Place the safeguard of the motor back.

Important: Never work with the motor safeguard while the transmission is removed, as this can cause serious accidents.

3.3 MAINTENANCE, INSPECTION AND CONTROL

To keep the shear in good conditions, you need to check periodically the following points:

- 1 Check periodically **(each 40 hours of use)** the efficiency of the blades and if necessary to replace them, proceed as per the instructions manual.
- 2 Check **(monthly)** the level of oil with the visor **B, Fig.5 y 5.1** and fill up if the level is below the stopper **A, Fig.5 y 5.1**. It is recommended to change the oil every two years.

TABLE OF OIL EQUIVALENCES ACCORDING TO MANUFACTURERS

Manufacturers	TYPE OF OIL
CEPSA	ENGRANAJE-HP 320
SHELL	OMALA 320
ESSO	SPARTAN EP-320
REPSOL	SUPERTAURO 320

3 Grease **(every 100 hours of use)** the connecting rod by the nipple **F, Fig. 5.1** with consistent grease. The CEL-45 model has another point of lubrication with oil on top of the greasing of the connecting rod **D, Fig. 5.1**, which needs to be lubricated with the same oil that arrives to the reducer box, at this point of greasing, we lubricate the bronze bearing.

4 Check the state and the tension of the transmission belts. The latter is supposed to be always tight to avoid any sliding, which can cause a mal functioning of the machine.

5 All electrical or interior components installations are recommended to be effectuated by authorized people.

6 At the end of each day, unplug the machine.

7 If the machine is not covered, wrap it with impermeable cloth.

8 Clean periodically the visible parts of the machine and grease as necessary.

WARNING: Before performing any maintenance or cleaning, the power supply cable needs to be unplugged.

4. STARTING UP AND USING THE MACHINE

WARNING: All safety recommendations must be followed, either the ones mentioned in the present user manual or those complying with all labour risks prevention norms in every location.

WHEELWORK: SIMA CEL models do not need any wheelwork operations as they are specially designed to obtain the maximum performance from start.

NORMAL USE OF THE MACHINE:

The electrical shears have been designed to cut flat and reinforced steel bars for use in the structure and other construction components is in conformity with all applicable provisions of the Directive of Machines (98/37/CE) and the national applicable regulations. Each other use that has not been expressively indicated is considered abnormal. Any tool or accessory added or amended without written authorization from the manufacturer is considered inappropriate and dangerous. If any damage or injury is caused as a result thereof or by misuse of the machine, SIMA S.A. exempts all responsibility as manufacturer. The machine must be installed on a plane, firm and horizontal surface and the ground should not be soft. This machine **DOES NOT HAVE TO BE USED UNDER THE RAIN. ALWAYS WORK IN WELL ILLUMINATED AREAS.**

STEPS TO FOLLOW TO REALISE A CUTTING

1 Lift slightly the blades safeguard to save height of the flange and then drag it completely leftwards Fig.6 before you can lift it totally.

2 Resting the bars upon the roller so that you can easily move the bar forward as per the predetermined measurement. Place the bar in the throat between the two blades. Lower back the blades safeguard and push rightward to free the pedal (the mechanism that operates the cutting).

Note: CEL models are equipped with a safety system that when the blades safeguard is lifted, the blades would not be able to cut the material.

3 Once the safeguard has been released, we can effectuate a cutting, either by pressing the pedal or pulling the grip.

Never try to make a cut while the safeguard is lifted as the material to cut can leave the cutting throat and cause damage.

5. SOLUTIONS TO MOST FREQUENT ANOMALIES

ANOMALY	POSSIBLE CAUSE	SOLUTION
Motor does not start	Fault of the electrical power supply	Check the power supply in the switch board. Check the position of the circuit breaker and the residual current device in the switch board. Make sure the extension cable is in good state and its fitting in the two extremes is correct.
	activation of the thermal protection of the single-phase switch	Wait until the motor has cooled down and re-activate the thermal protection
	Switch damaged	Replace it
Motor starts very slowly and takes too long to reach its revolutions	Condenser damaged. (Single-phase motors)	Replace it
Cutting power is too low	Belt loose or blunt	Tighten the belt or replace it
	Blades blunt	Change the cutting face of the blade or replace it
	Power drop down of the motor	Let the technical service check the motor.
Premature wearing of the belts	The belts slide over the pulleys	Tighten the belts

6. ELECTRICAL CONNECTION

The extension cable used to feed the machine needs to have a minimum section of 4x2.5 mm² up to 25 meters long. For a superior distance 4x4 mm² can be used. In one of its ends, it is needed to connect a base normalised aerial of 3P+T or 3P+N+T compatible with the machine switch and in the other end, one normalised aerial pin of 3P+T ó 3P+N+T compatible with switchboard exit.

Machines with electrical motor should always be connected to a normalised switchboard that disposes of a magneto-thermal switch and a differential in accordance with the characteristics of the motor:

3Kw /4 CV, three phase at 400V, 15A magneto-thermal and 15A/30mA differential.

4Kw / 5.5 CV, three phase at 400V, 10A magneto-thermal and 10A/30mA differential.


The machine electrical tension is visible on the voltage indication next to the top of engine terminals and on the machine characteristics plate.

WARNING: Do not plug the machine to the electricity if you are not sure of the available electrical tension. If the tension is not correct, the engine will undergo irreparable harm or out of service.

WARNING: Never manipulate the power cables or any electrical equipment of the machine, if you have not totally unplugged the machine from the electricity.

Once you have brought the rotation direction of the engine back, the machine is ready to operate.

IMPORTANT: It is appropriate to change the position of the bridge plates in the engine terminals. It is also important to change the adhesive labels indicating the voltage, to reflect the change made.



7.2 SAFETY RECOMMENDATIONS

The electrical shears models CEL are to be used by trained people or people familiarized with their operation.

- Before starting up the machine please read the instructions and make sure safety norms are respected. Learn how to stop the machine in a fast and safe way.
- Place the machine on a plane surface. Connect the machine to the electricity only when you are sure of its stability.
- Start the machine only when you have mounted the safety guards that come with the machine.
- It is recommended to use safety glasses, safety boots, gloves etc. Please always use approved materials.
- Always use Individual Protection Equipment (IPE) in accordance with the type of work you are effectuating.
- Prohibit strangers to access the place of work of the machine.
- Work clothes are not supposed to have loose articles that can cling into movable parts of the machine.
- When you have to move the machine, unplug the electricity cables and block the moving parts of the machine.
- Always keep protection elements and the safety guards in their correct positions.
- The damaged electrical cables should be urgently replaced.
- Make sure the rotation sense is correct.
- Unplug the machine from the electricity and never manipulate nor operate on the mechanical nor electrical elements of the machine while the engine is on.
- Visually control the joints, bolts, nuts, wildings, corrosion, etc.
- Never leave the machine with the engine switched on.
- Never use the machine for purposes other than those it has been designed for.

VERY IMPORTANT: Always use earth plug before starting-up the machine.

- Use normalised cables
- Make sure the feeding voltage is in accordance with the voltage indicated in the adhesive label on the machine.
- Make sure that the extension cords are not in contact with points of high temperature, oil, water, sharp edges. Also avoid trampling or crushing the cables by passing vehicles and do not put any objects on the machine.
- Do not use high pressure water to clean circuits or electrical elements.

ATTENTION: You are to follow all safety recommendations mentioned in the present user manual and comply with all labour risks prevention norms in every location.

SIMA, S.A. is not responsible for the consequences possibly generated but the inadequate use of the bending or the electrical shear, models CEL.

8. WARRANTY

SIMA, S.A. the manufacturer of light machinery for construction possesses a net of technical services "SERVI-SIMA".

Repairs under warranty made by SERVÍ-SIMA are subject to some strict condition to guaranty a high quality and service.

SIMA S. A. guarantees all its products against any manufacturing defect; to take into account the conditions stated in the attached document "WARRANTY CONDITIONS". The latter would cease in case of failure to comply with the established payment terms. SIMA S.A. reserves its right to bring modifications and changes to its products without prior notice.

9. SPARE PARTS

The spare parts for the bending and combined machines, manufactured by SIMA, S.A. are to be found in the spare parts plan, attached to this manual.

To order any spare part, please contact our alter-sales service clearly indicating the serial number of the machine, model, manufacturing number and year of manufacturing that show on the characteristics plate.

10. DECALARATIONS ON NOISE

The acoustic levels emitted by the MACHINE are inferior to 70 dB (A)


11. DECLARATIONS ON MECHANIAL VIBRATIONS

The machine does not present any source of mechanical vibrations that cause risks to the health or safety of the operator.

12. ENVIRONMENT PROTECTION



Raw materials have to be collected instead of throwing away residuals. Instruments, accessories, fluids and packages have to be sent into specific places for ecological reutilisation. Plastic components are marked for selective recycling.



R.A.E.E. Residuals arising of electrical and electronic instruments have to be stored into specific places for selective collection.

